

Desk Clamp Base (VESA:200x100)

Step 1

Option A

Option B

Min. 8.0mm

5mm

2.5mm

Step 2

Grommet Mount Base

Step 1

6mm

Step 2

D

G

2.5mm

Desk Stand

Step 1

K

O

Step 2

D

G

2.5mm

Desk Clamp Base (VESA:100x100)

Step 1

Option A

Option B

Min. 8.0mm

5mm

2.5mm

Step 2

D

G

2.5mm

Kensington lock hole

Dual Type Installation Process (VESA:200x100)

Step 3

C

H

Step 4

D

G

2.5mm

Step 5

B

J

B

Step 6

F

A

E

Step 7

Lock up

Notice

Dual Type Installation Process (VESA:100x100)

Step 3

C

H

Step 4

D

G

2.5mm

Step 5

B

J

B

Step 6

F

A

E

Step 7

Lock up

Notice

Step 8

3-4mm

Do Not Tighten the screws!

Step 9

Lock up

Notice

Step 10

Tighten the monitor screws!

Notice

Lock up

Additional Installation Process (For Quad Model only)

B

J

D

C

B

H

D

N

K

M

Additional Installation Process (For Quad Model only)

B

J

D

C

B

H

D

N

K

M

Swivel

+/-15°

+/-15°

Note: It's recommended to move arms at ultimate swivel angles before tilt to be adjusted.

Rotate(Pivot)

360°

90°

Arm Adjust(For each Arm)

15°

15°

L

5mm Allen wrench

Swivel

+/-15°

+/-15°

Note: It's recommended to move arms at ultimate swivel angles before tilt to be adjusted.

Rotate(Pivot)

360°

90°

Arm Adjust(For each Arm)

15°

15°

L

5mm Allen wrench

Cable Management

Horizontal & Vertical Adjust

Cable Management

Horizontal & Vertical Adjust

Swivel

+/-15°

+/-15°

Note: It's recommended to move arms at ultimate swivel angles before tilt to be adjusted.

Rotate(Pivot)

360°

90°

Arm Adjust(For each Arm)

15°

15°

L

5mm Allen wrench

Swivel

+/-15°

+/-15°

Note: It's recommended to move arms at ultimate swivel angles before tilt to be adjusted.

Rotate(Pivot)

360°

90°

Arm Adjust(For each Arm)

15°

15°

L

5mm Allen wrench

Cable Management

Horizontal & Vertical Adjust

Cable Management

Horizontal & Vertical Adjust